

Note: Refer to the C53 Owner's Manual pages 7&8 for additional connection information. Turntable with Moving Coil Cartridge Connection Legend: Data Cable\*-Digital Signal Cable -RS232 Cable -Sensor/Keypad Cable -Power Control Cable\* -Ground Wire -Audio Signal Cable -AC Power Cords -Video Signal Cable -Loudspeaker Cable -RF Signal Cable -\* 2 conductor shielded with 1/8 inch stereo mini phone plug on each end. Media Bridge AUDIO OUTPUTS

UNBALANCED

BALANCEE SPDIF OR ጆ (€ 4 (<del>4</del>) Milntosh C53 AUDIO PREAMPLIFIER  $\left( \circ _{\circ }\right)$  $(\circ,\circ)$  $\left( \circ \right)$ AM/FM Tuner 4 RAA2 AM ANT 120V **○** 50/60Hz 30 WATTS 0 **O** 0 HDMI (ARC) 0 0 0 0 0 TRIG 2 McIntosh DA2 DIGITAL AUDIO MODULE Connect to ( 🗵 SERIAL NUMBER AC Outlet SACD/CD Transport TV/Monitor DIGITAL AUDIO OUTPUTS
XLR DIN Digital Audio Player POWER
CONTROL DATA IR
IN OUT IN IN Computer DIGITAL UNBAL DIGITAL UNBAL

OPTICAL OPTICAL

ALIENCE TO THE PROPERTY OF THE P SERIAL NUMBER USB 5V/0.5A DC IN 5V

Use Oily The Prover Adaptic Provide DIGITAL AUDIO OUTPUTS C€ SERIAL NUMBER HDMI 3 (ARC)



Note: Refer to the C53 Owner's Manual page 8 for additional connection information.

